

ACER

OPERATION MANUAL

HIGH SPEED ENGINE LATHE DYNAMIC 1340G & 1440E

Revised : 01/18/16


Taiwan : Ya-Gin Machine Tool Manufacturing Inc.
Ya-Wei Machine Tool Manufacturing Inc.
No. 101 Lane 506, Seng-Tso Rd., Seng Karng District,
Taichung City, 429 Taiwan
Tel: 886-42-520-4120 Fax: 886-42-520-4123

NJ : Klim Industrial, Inc.
244 N. Randolphville Rd.,
Piscataway, NJ 08854 USA
Tel: 732-752-9100 Fax: 732-752-9101

CA : Springwood Industrial, Inc.
2320 E. Valencia Drive
Fullerton, CA 92831 USA
Tel: 714-871-5558 Fax: 714-871-5554

IMPORTANT

Before operating the machine, please read operating instruction pages 4~34 carefully!





Note: American style has apron handwheel on the left hand side!

INDEX

* SPECIFICATIONS AND ACCESSORIES	3
* GENERAL LAYOUT OF LATHE	4
* UNCRATING, CLEANING, LIFTING OF THE MACHINE	5
* INSTALLATION	8
* LATHE ALIGNMENT	9
* LEVELING	10
* TRANSPORTATION/INSTALLATION SITE	11
* FOUNDATION DIAGRAM	12
* CHUCK AND CHUCK MOUNTING	13
* TAPER TURNING ATTACHMENT	14
* LATHE CONTROL	15
* MAIN MOTOR CONTROL & FOOT BRAKE	16
* CONTROL PANEL	17
* APRON CONTROLS, CROSS SLIDE & TOPSLIDE	18
* SLIDWAYS ATTENTION & CROSS-SLIDE NUT	19
* TAILSTOCK	20
* ADJUSTMENT OF SLIPPING CLUTCH	21
* SPINDLE BEARING ADJUSTMENT	21
* THREAD AND FEEDS	22
* LUBRICATION CHART	23
* LUBRICATION CHECKS	24
* LUBRICATION CHECK	25
* LUBRICATION	26
* CE CHARACTERISTICS	27
* CE NORMS ELECTRIC COMPONENTS	28
* CE NORMS WIRING CIRCUIT DIAGRAM	29
* CE MARKING ELECTRIC COMPONENTS POSITION	30
* WIRING DIAGRAM (SINGLE PHASE)	31
* ELECTRIC COMPONENTS POSITION	32
* WIRING DIAGRAM (THREE PHASE)	33
* ELECTRIC COMPONENTS POSITION	34
* MECHANICAL PARTS LIST	35
* ELECTRIC EQUIPMENT	72
* NOTES	73
* TROUBLE SHOOTING	74
* TOLERANCE PERMISSIBLE DIAGRAM	75

SPECIFICATIONS AND ACCESSORIES

MODEL: Dynamic-1340G (13"× 40")
 Dynamic-1440E (14"× 40")



SPECIFICATIONS:

DESCRIPTION	METRIC SYSTEM		INCH SYSTEM	
	300 × 1000	360 × 1000	1340G	1440E
SWING OVER BED	330	360	13"	14"
SWING OVER CROSS SLIDE	195	225	6 1/2"	6 1/2"
DISTANCE BETWEEN CENTERS	1000		40	
SWING OVER GAP	490	520	19-1/4"	20-3/4"
WIDTH OF BED	190		7-9/16	
NUMBERED OF SPINDLE SPEEDS	9			
RANGE OF SPINDLE SPEEDS	80-2000R.P.M.			
HOLE THROUGH SPINDLE	40mm		1-1/2"	
SPINDLE NOSE	D1-4 Camlock			
TAPER OF SPINDLE BORE	M.T.No.5			
TAILSTOCK QUILL TAPER	M.T.No.3			
TAILSTOCK QUILL TRAVEL	110mm		4 3/8"	
CROSS SLIDE TRAVEL	175mm		6 7/8"	
COMPOUND REST TRAVEL	100mm		4"	
METRIC THREADS	(30)0.4-7.0MM		(30)0.4-7.0MM	
INCH THREADS	(32)4-56TPI		(32)3-56TPI	
LONGITUDINAL FEEDS	0.068-0.936mm/REV		0.0016"-0.03 /REV	
CROSS FEEDS	0.034-0.468mm/REV		0.0008"-0.015 /REV	
MACHINE NET WEIGHT	600 KG	620 KG	1320 Ib	1364 Ib
GROSS WEIGHT	700 KG	720 KG	1540 Ib	1584 Ib
CRATE DIMENSION L × W × H	1905 × 762 × 1473		75" × 30" × 58"	

STANDARD ACCESSORIES


- 2HP 1PH/3HP 3PH main drive motor
- Rapid foot brake
- 4-ways tool post

- Thread dial
- Gap bed
- Centers, M.T.No.3
- Center sleeve, M.T.No.5 × 3
- Set of change gears
- Tool kit & box
- Complete electric control unit
- Dual dials
- Face plate 10"(250mm)
- Steady rest
- Follow rest
- Rear splash guard
- 1/8HP coolant pump

OPTIONAL ACCESSORIES

- 3-jaw scroll chuck 6"(150mm)
- 4-jaw independent chuck 8"(200mm)
- Quick change tool post
- Single tool post
- Taper turning attachment
- Carriage micro stop
- Live centers MT#3
- Work lamp
- Drill chuck 13mm(1/2")w/arbor
- Chuck guard
- 4-position carriage stop
- Milling Attachment

GENERAL LAYOUT OF LATHE



- | | |
|---------------------------|------------------------------------|
| 1. HEADSTOCK | 10. LEAD SCREW |
| 2. SPINDLE | 11. SPINDLE ROTATION CONTROL LEVER |
| 3. TOP SLIDE | 12. CHIP PAN |
| 4. SADDLE AND CROSS-SLIDE | 13. APRON |
| 5. SPLASH GUARD | 14. FOOTBRAKE |
| 6. TAILSTOCK | 15. RACK |
| 7. BED | 16. GEAR BOX |
| 8. MOUNTING FEET | 17. END COVER (GEAR TRAIN) |
| 9. FEED SHAFT | 18. FORWARD/REVERSE CONTROL SHAFT |
| | 19. CONNECTION PLATE |

UNCRATING THE MACHINE

Upon receipt of shipment, remove crate carefully but do not remove skid until the lathe has been moved to the select area for its lifting.

CLEANING THE MACHINE

Do not move the carriage or tailstock on the bedways before cleaning thoroughly and lubricate the slideways. Use a good solvent to remove cosmoline and dirt accumulated in transit. Use rags rather than cloth to clean the slideways to eliminate lint. Do not use an air hose, as this will force grits and dirt onto important functioning units. Use a stiff bristle brush to get into corners and to clean leadscrew thoroughly.

When the machine has been cleaned satisfactorily, rub clean way lube oil onto all slideways and make sure there are no grits or dirt remains. Before moving the carriage on the bed, remove the filler plug on the top of the carriage and fill in with the specified oil on the lubrication chart.

Lubricate carriage ways on bed, then moving the carriage to balance the load. Also check the end gear-train for proper meshing of gears.

****Before operating any control, remove the anticorrosion coating from all slideways and end gear train by using white spirit or kerosene.**

****Do not use cellulose solvents for cleaning as they will damage the paint finish.**

****Oil all ground surfaces immediately after cleaning. Use machine oil or way lube oil to do the work. Use heavy oil or grease on the gear train.**

LIFTING THE MACHINE


To obtain a balanced condition before lifting, it is necessary to move tailstock to the end of the right hand bed way and clamp it there. Make sure to clean bed ways before moving carriage or tailstock.

Use the bed clamping plate and eyebolt to sling the lathe. Position the saddle and tailstock along the bed to obtain balance. Raise and lowering the machine should be done carefully, especially when you are lowering the machine. Be sure not to bump the machine against the floor.

*****Important: Do not use slings around bed as leadscrew and feed**

shaft may be bent.

*****Please see the following figure....**



NOTE:

Make sure the load is balanced and that sling does not touch the leadscrew or control rod before lifting.


If a crane is used in lifting, exercise care that none of the mechanism is damaged. Chain, wire cable or rope may be used to lift the lathe.

If ropes are used, be certain that they are strong enough to safely carry the weight of the machine. The finished surfaces of the machine must be protected from chains by using wooden blocks.

****After you receive the machine, please check if the packing contents all the accessories you ordered.**

The proper method to lift the machine is shown on next page, please make sure all parts are set before lifting!

*****The following figures shown lifting by crane and clamping plate.**




INSTALLATION

Located the machine on a solid foundation, and allowing sufficient area all around for easy working and maintenance (see foundation plan). The lathe may be leveled on the foundation or bolted to the foundation.

Free standing: Position lathe on foundation and adjust each of the six mounting screws to take equal pressure. Then use an engineer's precision level on the bedway to adjust the screws to level up the machine. Periodically check bed level to ensure continued lathe accuracy.

Fixed installation: Position lathe over six bolts (1/2 inch or 12mm dia.) that are set into the foundation and are correspond to the mounting feet position. Accurately level the machine, then tight the holding nuts. Re-check be level.




LATHE ALIGNMENT

Tailstock check

Using a 12 inch (305mm) ground steel bar fitted between headstock and tailstock centers, and check the alignment by fitting a dial test indicator to the topslide and traversing the center line of the bar.

To correct error, release the tailstock clamp lever and adjust the two set over screws provided. Continue the checking and correction until the alignment is within the specified tolerance.



LEVELING

Leveling the lathe

The lathe should be kept leveled at all times!

Leveling Procedure:

Clean the bedways thoroughly and make sure the bedways are bright after cleaning, then back off all leveling screws so the base is sitting on the leveling pads. Place a 6" precision machinist spirit level over a parallel if the level had a V base. Otherwise it can be directly placed on top of the flat cross-slide. Place the level lengthwise at the headstock end and level for a zero reading.

Move the level to the tailstock end and adjust the outer end leveling screws to obtain same reading as on the headstock end. Now place the level over a bridge across at the headstock end, take a reading and move the level to the tailstock end. The reading at this end must be exactly the same as the other end. No twist is permissible. Make adjustments to get the same reading at both ends. It will be necessary to repeat this procedure several times before it is done. For making necessary adjustments, you will find that adjustment at one end will affect the reading of the other. After the end leveling screw adjustments are complete, turn down the center leveling screws at the headstock end until they rest under slight tension. The tension should be such that it does not change the level reading.


Re-check level at this time and make only minor adjustment if necessary. After the machine has been put to use for a period of time, check level to observe if original leveling accuracy exists, make adjustments if necessary.

Note: Mark one end of the level with a erasable marker so that the level points in the same direction for every reading.

Carpenter's or combination square level is not accurate and must not be used. Schedule a periodic level check as part of your maintenance schedule.

*****See figure on next page.**

POSITIONING OF SPIRIT LEVELS



TRANSPORTATION/INSTALLATION SITE

PREPARATION FOR USE


Selecting location for machine:


For best result for any lathe, it is important that the site selected for its location be well lighted as dry as possible and as free as possible from vibration.

The machine should be located so that adequate space is provided for utilization of maximum range, as well as the space required for making adjustments. A minimum of 28 inches clearance space should be provided at the ends and rear of the lathe and at least 40 inches at the front for the operator.

Foundation:

A special foundation is not essential for this machine. However it is advisable to place it on a substantial foundation of concrete if it is possible. If placed on a wooden floor, care should be taken to see that it is adequately supported and free from vibration. If the machine is to be placed on an upper floor, locate it directly over a supporting beam to reduce any vibration generated by nearby machines.





CHUCKS AND CHUCK MOUNTING


When fitting chucks or face plates, first make sure that spindle and chuck tapers are perfectly clean and that all cams lock in the correct positions, see fig. It may be necessary when mounting a new chuck to re-set the camlock studs (A). To do this, remove the cap head locking screws (B) and set each stud so that the scribed ring (C) is flush with the rear face of the chuck with the slot lining up with the locking screw hole.

Now mount the chuck or face plate on the spindle nose and tighten the six cams in turn. When fully tightened, the camlock line on each cam should be between the two V marks on the spindle nose.

If any of the cams do not tighten fully within these limit marks, remove the chuck or face plate and re-adjust the stud as indicated in the illustration. Fit and tighten the locking screws (B) at each stud before mounting the chuck for work. A reference mark should be made on each correctly fitted chuck or face plate to coincide with the reference mark scribed on the spindle nose.


This will assist subsequent remounting: Do not interchange chucks or face plates between lathes without checking for correct cam locking before hand.

*****Important: Take careful note of speed limitation when using face plate; 10" face plates should not run at speeds greater than 1,000 rev/min, and 12" face plates at no more than 750 rev/min.**




INSTRUCTION FOR ASSEMBLING TAPER TURNING ATTACHMENT ON ACER LATHE

1. Loosen cross feed nut (E).
2. Fitting taper turning attachment onto carriage and then locked by screw.
3. Adjust (A) parallel to the bed within 0.015mm/150mm by dial indicator.
4. Install (F) on (D).
5. Put (B) on cross slide and locked by screw.
6. Lock (B) on (D) by nut.
7. Set bracket (C) on bed.




LATHE CONTROL



1. SPINDLE SPEED SELECTOR
2. SPEED SELECT LEVER
3. CROSS SLIDE FEED HANDWHEEL
4. TOOLPOST CLAMPING LEVER
5. TOP-SLIDE HANDWHEEL
6. SADDLE CLAMPING LEVER
7. TAILSTOCK BARREL CLAMPING LEVER
8. TAILSTOCK CLAMPING LEVER
9. TAILSTOCK HANDWHEEL
10. POSITIVE-REVERSE LEVER
11. FEED AND THREAD SELECTORS
12. FOOT BRAKE
13. APRON LONGITUDINAL FEED HANDWHEEL
14. AUTOMATIC FEED LEVER
15. THREAD CUTTING HALF-NUT LEVER
16. SPINDLE ROTATION (FORWARD AND REVERSE)

MAIN MOTOR CONTROL & FOOT BRAKE




*** Main motor rotation:

Selected by the lever controls (the located on right hand side of the apron). Move lever out and upward to engage forward rotation of spindle. Or out and down to engage reverse rotation. Or returned to the central position to disengage drive.

*** Foot brake:

A foot pedal between two bases operates the spindle brake.

CONTROL PANEL



*****Caution: Do not shift gears when the spindle is running.**

- 1. The emergency stop: Press the red mushroom-headed button to stop the main motor and coolant pump.**
- 2. Jogging button: Press the green button to move spindle slightly. It will make spindle speed selection very easy (while the spindle rotation lever is set in the neutral position).**
- 3. Pilot lamp.**
- 4. Coolant pump on/off switch.**

APRON CONTROLS

In addition to handwheel traverses, the carriage can be power operated through controls on the front of the apron. Automatic feed lever (A): If move upward, carriage will do longitudinal feeding operation. If move lever (A) in middle position, it will do manual operation. If move lever (A) downward, it will do cross feeding operation.


Lever (B) is pressed downward to engage the leadscrew nut for thread cutting. To avoid undue wear, release the nut when not thread cutting. An interlock within the apron prevent inadvertently engagement of automatic feed lever (A) and half nut lever (B) at the same time.



CROSS SLIDE AND TOPSLIDE


A solid topslide is fitted as standard to the cross-slide, and is carried on a rotative base. The cross slide is marked $45^{\circ} - 0^{\circ} - 45^{\circ}$ for accurate indexing. Handwheel dials are graduated in inch-or-metric division to suit the operating screw and nut.

The cross slide can be power operated by pulling downward the automatic feed lever at half sliding feed per spindle revolution or it can be hand operated using the large diameter dial graduated in either inch or metric divisions to suit the operating screw and nut.




SLIDEWAYS ATTENTIONS

Tapered gibs are fitted to slideways of saddle, cross-slide and top (compound) slides so that any slackness, which may develop can be reduced. Make sure that slideways are thoroughly cleaned and lubricated before attempting adjustment, then reset the gibs by releasing the rear gib screw and tightening the front screw a little at a time. Check constantly for smooth action through out full slide travel; avoid over adjustment, which can result in increased wear rate and stiff or jerky action of the movement.



CROSS-SLIDE NUT


This is adjustable for eliminating slackness, which may develop in operation. Reduce backlash by the cap head screw located at the rear of the nut. Then make only small adjustment by the cap head screw. Before operating the cross slide several times by hand to be sure of smooth operation through out travel.



TAILSTOCK


Tailstock can move freely along the bed by unlocking the clamp lever (A). The tailstock barrel is locked by lever (B).

The tailstock can be set over for production of shallow tapers or for re-alignment. Release the clamping lever (A) and adjust screw (S) at each side of the base to move tailstock laterally across the base. Re-tighten and checking after adjustment of re-alignment.




ADJUSTMENT OF SLIPPING CLUTCH

Apron has an overload protection device by means of slipping clutch. This adjustment can be accomplished by adjusting screws (S). Be sure not to adjust these screws so frequently, because slipping clutch does not wear so much even for a long period of usage.



SPINDLE BEARING ADJUSTMENT

When we find the spindle bearings are too tight or loose, we need to open the headstock cover (A) and loosen the set screw (B) on the spindle bearing thrust nut (C) and then adjust the thrust nut by loosening or fastening it. The proper adjustment is finished by fastening the set screw again.



THREADS AND FEEDS

****FOR INCH GEAR BOX****

Check the chart for the desired feed and turn the change lever (W, X, Y, Z) and (P, Q, R, I, T) and turn the selector knob (A, B), (C, D) in the gear box to obtain the desired speed shown on the right chart.

CAUTION

DO NOT CHANGE GEARS AND FEEDS WHEN SPINDLE IS IN HIGHER SPEED RANGE!


		T.P.I.				INCH			
	P	Q	T	R	R	Q	R		
	X	X	Z	X	X	Z	W		
	60	65	60	60	57	60	60	60	
AD	3	3 1/4	4	4 1/4	4 3/4	5	5 1/2	7	
BD	6	6 1/2	8	9	9 1/2	10	11	14	
AC	12	13	16	18	19	20	22	28	
BC	24	26	32	36	38	40	44	56	
		PITCH				MM			
	28	28	42	35	49	30	49	36	
	R	Q	R	Q	R	Q	Q	Q	
	W	W	W	W	X	W	X		
AD	3.2	4.0	4.8	5.0	5.6	6.0	7.0	7.2	
BD	1.6	2.0	2.4	2.5	2.8	3.0	3.5	3.6	
AC	0.8	1.0	1.2	1.25	1.4	1.5	1.75	1.8	
BC	0.4	0.5	0.6		0.7	0.75		0.9	
		FEED				MM			
	I	I	I	I					
	W	X	Y	Z					
AD	0.021	0.0295	0.0638	0.0226					
BD	0.0105	0.0148	0.0184	0.0113					
AC	0.0053	0.0072	0.0092	0.0056					
BC	0.0026	0.0036	0.0046	0.0028					

		PITCH				MM			
	T	U	S	U	S	R	U	R	
	Y	X	Y	Z	Y	Z	Z		
AD	3.2	3.6	4.0	4.8	5.0	5.6	6.0	7.0	
BD	1.6	1.8	2.0	2.4	2.5	2.8	3.0	3.5	
AC	0.8	0.9	1.0	1.2	1.25	1.4	1.5	1.75	
BC	0.4	0.45	0.5	0.6		0.7	0.75		
		T.P.I.				INCH			
	U	S	T	U	T	T	T		
	X	Y	X	X	X	X	X		
	48	60	38	60	44	48	52	56	
AD	4	4 1/2	4 3/4	5	5 1/2	6	6 1/2	7	
BD	8	9	9 1/2	10	11	12	13	14	
AC	16	18	19	20	22	24	26	28	
BC	32	36	38	40	44	48	52	56	
		FEED				MM			
	X	Y	Z						
PAD	0.554	0.752	0.936						
PBD	0.272	0.376	0.468						
PAC	0.136	0.188	0.234						
PBC	0.068	0.094	0.117						

****FOR METRIC GEAR BOX****

Check the chart for the desired feed and turn the change lever (X, Y, Z) and (R, S, T, P, U) turn the selector knob (A, B), (C, D) in the gear box. To obtain the described speed shown on the left chart.

LUBRICATION CHART



CAUTION ON OILING

The following cautions are very important to be followed when oiling:

1. Use only specified oil or grease with specified quantity. To use oil or grease other than specified and too much oil or grease may adversely affect the performance of the machine.
2. Clean the slideways, oil filler holes, oil tank, etc., before pouring oil and take care not to pollute the oil when pouring it.
3. When pouring oil, place a filter over oil filler hole to eliminate dust and dirt. If a filter is not available, use a wire net of 150 mesh or finer.
4. Successively use the identical oil or grease. Note that the use of oil having different properties might degrade the oil.

5. Even when the new oil is drained and used again for re-assembling, replacement of part or any other reason. Please be sure to filter the oil, when pouring it again.
6. Do not fully use oil can's oil, but leave a small quantity of oil in this can. This caution allows us to eliminate moisture and sediment from oil.

LUBRICATION CHECKS

A. HEADSTOCK

Headstock bearings and gears are splash lubricated. Ensure that oil level is kept between H-L level mark on the sight glass in the chuck face of headstock. After long time of operation, when the headstock lubrication oil becomes unclean, it should be drained out to refill fresh lubrication oil.

To change oil in the headstock, set apron control lever to central position and stop the main motor. Unscrew the drain plug beside headstock, then the oil tank can be easily drained out for changing oil. A filler plug is fitted beside the left end of the headstock, which is accessible after removal of the end cover.

B. GEAR BOX

The gear box is splash lubricated from an internal reservoir of oil. Check the oil level at the gauge of the gear box constantly to make sure that oil is enough. A weekly check of oil level, and semi-annual change of oil are recommended. Fill oil through a filler cap on the top of the gear box, which is enclosed by the left end cover, and you can drain oil from a drain plug at the bottom of the gear box.

C. APRON

Apron can be filled through the inlet on top of the saddle. Oil level must be kept with the center line of the oil gauge, which is located at the lower right corner of the apron. Oil is drained from the plug at the bottom of the apron.

Fill the apron with Shell Tonna oil #33 to the gauge level if necessary.

D. OTHER PORTIONS


There are oil inlets on the cross slide, compound rest, feed screw shaft bearings, tailstock, feed rod, leadscrew, and bracket that hold screw and rod. They need to be lubricated from time to time.

***Make sure that the slideways are thoroughly clean and lubricated before operating the lathe

LUBRICATION CHECK

BEFORE OPERATING THE MACHINE, PLEASE CHECK THE FOLLOWINGS:

- 1. The headstock is filled with oil to the gauge level. Fill it with Shell Tellus oil #27, if not enough.**
- 2. The gear box is filled with Shell Tellus oil #27 to the gauge level.**
- 3. Apron is filled to the gauge level with Shell Tonna oil #33.**
- 4. In addition, apply oil to the points on the lubrication diagram daily. Please use light machining oil or way lube oil.**




LUBRICATION

In addition to pump feed lubrication system, oil points are provided for the saddle, cross slide, and crossfeed nut. Use a hand-held oil pump to lubricate the points provided on the figure.


On the tailstock, a standard oil can is used to oil the tail end of the leadscrew.

It is recommended that all slideways, leadscrews, and feed rod are cleaned periodically, and lightly oiled after each period of work.


Note: Usage of incorrect type of lubrication oil can cause damage to the parts.




"CE" CHARACTERISTICS:



A CHUCK GUARD WITH LIMIT SWITCH IS FITTED. (The machine is stopped automatically when the chuck guard is lifted up.)




TOOL SLIDE GUARD IS MOUNTED ON THE SADDLE TO ENSURE OPERATION SAFELY.




LEAD SCREW IS INSTALLED WITH MOVABLE COVER PROTECTED TO ENSURE OPERATION SAFELY.



END COVER IS CONNECTED WITH A LIMIT SWITCH ON THE SIDE OF HEADSTOCK. (The machine is stopped automatically when the end cover is opened.)



A MAIN SWITCH IS MOUNTED ON THE DOOR OF ELECTRIC BOX TO CONTROL ELECTRIC SUPPLY.




ELECTRIC BOX CONTAINS "CE" STANDARD COMPONENTS.

FORMOSA SPRINGWOOD INTERNATIONAL, INC.


**Dynamic 1340G and 1440E motor for "CE" norms electric components
for 3HP 50/60HZ, 24V control.**

NO.	DESCRIPTION	BRAND	CODE	SPEC.	REMARK
1	MAGNETIC SWITCH	TAIAN	CN-11	380V/4KW	K1,K2,K5
2	MAGNETIC SWITCH	TAIAN	CN-11	380V/4KW	K3
3	MAGNETIC SWITCH	TAIAN	CN-11	380V/4KW	K4
4	OVERLOAD ROLAY	TAIAN	RHN-10M	0.3-0.464A/380V	F3
5	OVERLOAD ROLAY	TAIAN	RHN-10M	4-6A/380V	F2
6	POWER TRANSFORMER	ZIENTE	TC130VA/24V		TR 1
7	DOOR SWITCH	AB	194L-A16		Q 1
8	FUSE HOLDER	GEC ALSTHOM FMC 101	10 x38	32A/660V	MF
9	FUSE	GEC ALSTHOM FMC 101	10 x38	32A/660V	F5,F4
10	TERMINAL	AB	1492-W4	800V/15A	
11	LIMIT SWITCH	OMRON TE	D4BS-25FC XCK-P591		
12	LIMIT SWITCH	OMRON TE	D4D-1532N XCK-P102		
13	FOR/REV SWITCH	HIGHLY	Z15G/1306		
14	PUMP SWITCH	TE	ZB2-BE101		
15	PUSH BUTTON	TE	ZB2-BE101		
16	PILOT LIGHT	TE	ZB2-BE101		
17	EMERGENCY SWITCH	TE	ZB2-BE102		



"CE" NORMS WIRING CIRCUIT DIAGRAM

"CE" MARKING ELECTRIC COMPONENTS POSITION



T1: CONTROL CIRCUIT TRANSFORMER.

K2: FOR MAIN MOTOR REVERSE AC MAGNETIC CONTACTOR COIL.

K1: FOR MAIN MOTOR FORWARD AC MAGNETIC CONTACTOR COIL.

K3: FOR PUMP MOTOR AC MAGNETIC CONTACTOR COIL.

K4: AC MAGNETIC CONTACTOR COIL.


F2,F3: THERMAL OVERLOAD RELAY.

F4,F5: CIRCUIT TRANSFORMER WITH FUSE 32A/660V.


Q1: DOOR SWITCH.

MF: MAIN POWER FUSE.

WIRING DIAGRAM (1 PHASE)



ELECTRIC COMPONENTS POSITION



*** THIS IS STANDARD ELECTRIC WIRING DIAGRAM IS WIRED FOR 220 VOLTS SINGLE PHASE 50/60 CYCLES.

FOR CONNECTION TO 380 OR 440 VOLTS MOVE THE (S) LINE TO 380 OR 440 ON THE TRANSFORMER AND INTERCHANGE MOTOR WIRED CORRESPOND 380 OR 440 VOLTS WITH POWER SUPPLY.

**** SINGLE PHASE W/FOOT BRAKE AND PUMP ****

CS1 : PUMP MOTOR SELECTING SWITCH

TR : CONTROL CIRCUIT TRANSFORMER

M1 : FOR MAIN MOTOR REVERSE AC MAGNETIC CONTACTOR COIL

M2 : FOR MAIN MOTOR FORWARD AC MAGNETIC CONTACTOR COIL

P : FOR PUMP MOTOR AC MAGNETIC CONTACTOR COIL

C1 : AC MAGNETIC CONTACTOR COIL

O.L : THERMAL OVERLOAD RELAY

F2 : FUSE 5A

B1 : EMERGENCY STOP BUTTON


PB2 : INCHING BUTTON

LS2 : LIMIT SWITCH FOR FOOT BRAKE


LS3 : LIMIT SWITCH FOR MAIN MOTOR REVERSE

LS4 : LIMIT SWITCH FOR MAIN MOTOR FORWARD

WIRING DIAGRAM (3 PHASE)



ELECTRIC COMPONENTS POSITION



*** THIS IS STANDARD ELECTRIC WIRING DIAGRAM IS WIRED FOR 230 VOLTS THREE PHASE 50/60 CYCLES.

FOR CONNECTION TO 380 OR 460 VOLTS MOVE THE (S) LINE TO 380 OR 460 ON THE TRANSFORMER AND INTERCHANGE MOTOR WIRED CORRESPOND 380 OR 460 VOLTS WITH POWER SUPPLY.

** THREE PHASE W/FOOT BRAKE AND PUMP **

CS1 : PUMP MOTOR SELECTING SWITCH

TR : CONTROL CIRCUIT TRANSFORMER

M1 : FOR MAIN MOTOR REVERSE AC MAGNETIC CONTACTOR COIL

M2 : FOR MAIN MOTOR FORWARD AC MAGNETIC CONTACTOR COIL

P : FOR PUMP MOTOR AC MAGNETIC CONTACTOR COIL

C1 : AC MAGNETIC CONTACTOR COIL

O.L : THERMAL OVERLOAD RELAY

F2 : FUSE 5A

B1 : EMERGENCY STOP BUTTON

PB2 : JOGGING BUTTON

LS2 : LIMIT SWITCH FOR FOOT BRAKE


LS3 : LIMIT SWITCH FOR MAIN MOTOR REVERSE

LS4 : LIMIT SWITCH FOR MAIN MOTOR FORWARD

Mechanical Parts List


When ordering parts, please specify the following:

- 1. Model & year of production**
- 2. Part number, page number & description**
- 3. Quantity**




HEADSTOCK (CASTING & CONTROLS)

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2101	HEADSTOCK CASTING	1	
2	2143	HEADSTOCK COVER	1	
3	2121	SHAFT	1	
4	2122	GEAR (M2X32T)	1	
5	2123	WASHER	1	
6	2124	SHAFT	1	
7	2125	GEAR (M2X38T)	1	
8	2126	HANDLE	1	
9	2127	GEAR SHIFT FORK	1	
10	2136	SHAFT	2	
11	2137	FORK ARMS	2	
12	2138	GEAR SHIFT FORK	2	
13	2139	COLLAR	2	
14	2141	HANDLE	2	
15	2142	CONTROL LEVER	2	
16	2194	OIL RING	2	
17	2193	PIN (5mmx32mm)	2	
18	2184	CAP SCREW (6mmx25mm)	6	
19	2195	PLUG (3/8 G.P.)	1	
20	2144	OIL SIGHT(29mm)	1	
21	2181	OIL RING(P20)	1	
22	2182	SNAP RING (S18)	1	
23	2178	WASHER	1	
24	2180	BEARING (6004)	2	
25	2145	KEY(5mmx18mm)	1	
26	2146	OIL RING (P12)	1	
27	2188	SNAP RING (S40)	1	
28	2185	INDICATOR PLATE	3	
29	2191	OIL RING (P12)	2	
30	2189	CAP SCREW (6mmx16mm)	4	
31	2192	SPRING PIN (5mmx40mm)	2	
32	2186	STEEL BALL SPRING & SET SCREW	2	8mmx6mm
33	2190	PVC KNOB	2	
34	2183	PLUG (5/8")	1	
35	2196	DATA PLATE	1	
36	2197	SCREW (3/16"x3/8")	4	




HEADSTOCK (SPINDLE & GEARS)

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
10	2112	SHAFT	1	
11	2116	GEAR (M2x19T)	1	
12	2117	GEAR (M2x60T)	1	
13	2118	GEAR (M2x52T)	1	
14	2119	BORE PLUG	1	
15	2120	COVER	1	
16	2113	GEAR (M2x30T)	1	
17	2114	GEAR (M2x50T)	1	
18	2115	GEAR (M2x40T)	1	
19	2135	COVER (BACK)	1	
20	2134	LOCK NUT	1	
21	2133	GEAR (M2x38T)	1	
22	2132	GEAR (M2x80T)	1	
23	2131	GEAR (M2x39T)	1	
24	2130	GEAR (M2x48T)	1	
25	2128	COVER (FRONT)	1	
26	2129	MAIN SPINDLE	1	
38	2162	SNAP RING (S25)	1	
39	2163	KEY (6mmx22mm)	2	
37	2158	BEARING (#6204)	2	
40	2164	SNAP RING (S35)	1	
41	2165	SNAP RING (R47)	1	
42	2166	OIL RING (P39.4)	1	
43	2159	SCREW (CAP 6mmx16mm)	6	
44	2180	GASKET	1	
46	2161	SNAP RING (S45)	1	
48	2167	GASKET	1	
49	2134	SCREW (CAP 6mmx25mm)	2	
50	2168	BEARING (#30211)	1	
51	2169	SNAP RING (S55)	1	
52	2170	SNAP RING (S58)	1	
53	2171	BEARING (#30212)	1	
54	2172	GASKET	1	
55	2173	SCREW (CAP 6mmx25mm)	3	
56	2174	KEY (6mmx15mm)	1	
57	2175	KEY (7mmx75mm)	1	
58	2176	CAM D1-4	3	
59	2182	STUD	3	
60	2177	DETENT PLUNGER,SPRING AND SCREW	3	



MAIN MOTOR AND BRAKE SHOES ASSY


REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2111	NUT (M2xP1.5mm)	1	
2	2110	V-BELT PULLY	1	
3	2107	STUD	1	
4	2108	SHAFT LEVER	1	
5	2106	COVER	1	
6	2102	SHAFT	1	
7	2103	GEAR (M2x39T)	1	
8	2104	GEAR (M2x18T)	1	
9	2105	GEAR (M2x29T)	1	
18	2618	MOTOR PLATE	1	
19	2653	MOTOR PULLEY	1	
27	2178	WASHER	1	
28	2109	BRAKE SHOES ASSY	1	
29	2180	SPRING	2	
30	2151	SNAP RING	1	
31	2153	CAP SCREW	1	
32	2152	SCREW (CAP 6mmx25mm)	3	
33	2179	GASKET	1	
34	2155	BEARING (#6205)	1	
35	2156	KEY (6mmx30mm)	1	
36	2157	KEY (6mmx80mm)	1	
37	2158	BEARING (#6204)	1	
49	2619	WASHER	2	
50	2631	SCREW (CAP 10mmx35mm)	2	
51	2652	MAIN MOTOR	1	
52	2656	WASHER	4	
53	2657	SCREW (CAP 8mmx30mm)	4	
54	2659	KEY (8mmx45mm)	1	
55	2655	SCREW (SET 10mmx20mm)	1	
56	2654	V-BELT	2	



GEARBOX (CASTING & CONTROLS)

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2224	COVER	1	
2	2225	HANDLE	1	
3	2226	SHAFT	1	
4	2227	HANDLE	1	
5	2228	SHIFT LEVER	1	
6	2229	SHIFT LEVER	1	
7	2230	SHIFT FORK	3	
8	2231	LEVER	2	
9	2233	HANDLE	1	
10	2234	SHIFT FORK	1	
11	2241	SCREW (3/16x3/8 IN)	6	
12	2248	SCREW (CAP 6mmx30mm)	6	
13	2247	SET SCREW SPRING AND STEEL BALL	2	
14	2251	KEY (5mmx10mm)	1	
15	2244	OIL RING (P24)	1	
16	2243	SPRING PIN (5mmx40mm)	1	
17	2242	SPRING PIN (5mmx30mm)	1	
18	2250	PVC KNOB	2	
19	2253	SET SCREW SPRING AND STEEL BALL	2	
20	2246	OIL RING (P34)	2	
21	2245	SNAP RING (S40)	2	
22	2249	INDEXING PLATE	2	
23	2252	OIL SIGHT (29mm)	1	
24	2254	GASKET	1	
25	2232	HANDLE	1	
26	2240	DATA PLATE	1	


INCH TYPE



GEARBOX (GEAR & SHAFT) INCH TYPE

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2201	GEAR BOX CASTING	1	
2	2204	COVER	1	
3	2202	SHAFT	1	
4	2203	GEAR (M2x27TX18T)	1	
5	2236	GEAR (14Px27Tx30T)(M2.25x21T)	1	
6	2205	COVER	1	
7	2206	SHAFT	1	
8	2218	COVER	1	
9	2208	SHAFT	1	
10	2209	GEAR (M2x27T)	1	
11	2210	GEAR (M2x18T)	1	
12	2211	GEAR (M2x36T)	1	
13	2217	GEAR (M2.25x28T)	1	
14	2216	GEAR (14Px30T)	1	
15	2215	GEAR (14Px24T)	1	
16	2237	GEAR (14Px33T)	1	
17	2212	SPACER	1	
18	2213	SHAFT	1	
19	2222	COVER	1	
20	2220	GEAR (M2x36Tx18T)	1	
21	2235	GEAR (14Px24Tx30T)(M2.25x20T)	1	
22	2219	SHAFT	1	
23	2223	COVER	1	
24	2272	PIN (5mmx28mm)	2	
25	2273	CAP SCREW (8mmx30mm)	3	
26	2256	OIL SEAL (22x35x7)	1	
27	2255	CAP SCREW (6mmx20mm)	6	
28	2267	KEY (5mmx18mm)	1	
29	2258	KEY (6mmx40mm)	1	
30	2259	BEARING (6004)	3	
31	2260	SNAP RING (S20)	1	
32	2261	BEARING (6003)	5	
33	2262	NUT	1	
34	2269	WASHER	1	
35	2263	THRUST (51105)	3	
37	2275	CAP SCREW (6mmx20mm)	9	
38	2268	KEY (6mmx55mm)	1	
39	2266	SNAP RING (S25)	1	
40	2264	KEY (5mmx60mm)	1	
41	2265	KEY (5mmx12mm)	1	
44	2274	SNAP RING (S22)	2	
45	2276	OILER (5/16 IN)	1	
46	2277	SCREW (CAP 8mmx10mm)	1	


METRIC TYPE



GEARBOX (GEAR & SHAFT) METRIC TYPE

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2201	GEAR BOX CASTING	1	
2	2204	COVER	1	
3	2202	SHAFT	1	
4	2203	GEAR (M2x27TX18T)	1	
47	2207	GEAR (M2.25x20T)(14Px30T)(M2x25T)	1	
6	2205	COVER	1	
7	2206	SHAFT	1	
8	2218	COVER	1	
9	2208	SHAFT	1	
10	2209	GEAR (M2x27T)	1	
11	2210	GEAR (M2x18T)	1	
12	2211	GEAR (M2x36T)	1	
13	2217	GEAR (M2.25x28T)	1	
14	2216	GEAR (14Px30T)	1	
15	2215	GEAR (14Px24T)	1	
48	2214	GEAR (M2x30T)	1	
17	2212	SPACER	1	
18	2213	SHAFT	1	
19	2222	COVER	1	
20	2220	GEAR (M2x36Tx18T)	1	
49	2221	GEAR (M2.25x21T)(14Px30T)	1	
22	2219	SHAFT	1	
23	2223	COVER	1	
24	2272	PIN (5mmx28mm)	2	
25	2273	CAP SCREW (8mmx30mm)	3	
26	2256	OIL SEAL (22x35x7)	1	
27	2255	CAP SCREW (6mmx20mm)	6	
28	2267	KEY (5mmx18mm)	1	
29	2258	KEY (6mmx40mm)	1	
30	2259	BEARING (6004)	3	
31	2260	SNAP RING (S20)	1	
32	2261	BEARING (6003)	5	
33	2262	NUT	1	
34	2269	WASHER	1	
35	2263	THRUST (51105)	3	
37	2275	CAP SCREW (6mmx20mm)	9	
38	2268	KEY (6mmx55mm)	1	
39	2266	SNAP RING (S25)	1	
40	2264	KEY (5mmx60mm)	1	
41	2265	KEY (5mmx12mm)	1	
44	2274	SNAP RING (S22)	2	
45	2276	OILER (5/16 IN)	1	
46	2277	SCREW (CAP 8mmx10mm)	1	


RIGHT HANDWHEEL



APRON (CASTING)





REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2301	APRON CASTING	1	
11	2316	BRACKET	1	
12	2317	GEAR SHAFT (M1.5x16T)	1	
13	2318	LEVER	2	
14	2362	INDEXING PLATE	1	
23	2309	WORM	1	
24	2310	COLLAR	2	
25	2325	HALF NUT CLUTCH	1	
26	2326	GIB	1	
27	2358	OIL SIGHT (29mm)	1	
28	2357	CAP SCREW (8mmx10mm)	1	
29	2355	STEEL BALL SET SCREW AND SPRING	1	
30	2354	SET SCREW (6mmx10mm)	3	
31	2356	PLUG (5/8 IN)	1	
32	2352	SNAP RING (S 30)	2	
33	2353	CAP SCREW (6mmx20mm)	2	
39	2363	CAP SCREW (6mmx40mm)	4	
40	2360	CAP SCREW (8mmx25mm)	1	
41	2361	SCREW (3/16x3/8 IN)	3	
42	2359	PVC KNOB	2	

LEFT HANDWHEEL



APRON (CASTING)


REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2301	APRON CASTING	1	
11	2316	BRACKET	1	
12	2317	GEAR SHAFT (M1.5x16T)	1	
13	2318	LEVER	2	
14	2362	INDEXING PLATE	1	
23	2309	WORM	1	
24	2310	COLLAR	2	
25	2325	HALF NUT CLUTCH	1	
26	2326	GIB	1	
27	2358	OIL SIGHT (29mm)	1	
28	2357	CAP SCREW (8mmx10mm)	1	
29	2355	STEEL BALL SET SCREW AND SPRING	1	
30	2354	SET SCREW (6mmx10mm)	3	
31	2356	PLUG (5/8 IN)	1	
32	2352	SNAP RING (S 30)	2	
33	2353	CAP SCREW (6mmx20mm)	2	
39	2363	CAP SCREW (6mmx40mm)	4	
40	2360	CAP SCREW (8mmx25mm)	1	
41	2361	SCREW (3/16x3/8 IN)	3	
42	2359	PVC KNOB	2	



APRON (GEAR & SHAFT)


REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
2	2302	GEAR SHAFT(M2x12T)	1	
3	2303	KEEP ASSY	1	
4	2304	INDEX RING	1	
5	2305	HANDWHEEL	1	
6	2306	HANDLE	1	
7	2307	GEAR SHAFT (M1.5x13T)	1	
8	2308	GEAR (M2x50T)	1	
9	2314	SHAFT	1	
10	2315	GEAR(M2x22T)(M2x44T)	1	
15	2311	SHAFT	1	
16	2312	GEAR(M2x22T)	1	
17	2313	GEAR(M1.5x18T)	1	
18	2319	SHAFT	1	
19	2320	COLLAR	1	
20	2321	SHAFT	1	
21	2322	LEVER	1	
22	2323	HANDLE	1	
34	2340	CAP SCREW(6mmx16mm)	3	
35	2341	STEEL BALL AND SPRING	1	
36	2342	PIN (5mmx50mm)	1	
37	2343	PIN (5mmx30mm)	2	
38	2344	CIRCLIP (E12)	1	
43	2348	KEY (5mmx14mm)	2	
44	2346	SNAP RING (S14)	2	
45	2351	PIN (5mmx40mm)	1	

INCH TYPE(LEADSCREW 4TPI)



INDICATOR TABLE					
TP.1	SCALE	TP.1	SCALE	TP.1	SCALE
4	1-8	12	1-8	38	
4 1/2	1/2, 3/4	13	1-4	40	
4 3/4	1	14		44	
5	1-4	16	1-8	48	
5 1/2	1/2, 3/4	18		52	
6	1-8	19	1-4	56	1-8
6 1/2	1/2, 3/4	20		64	
7	1-4	22		72	
8	1-8	24		76	
9	1-4	26	1-8	80	
9 1/2	1/2, 3/4	28		96	
10	1-8	32		104	
11	1-4	36		112	


METRIC TYPE(LEADSCREW PICH 4MM)



INDICATOR TABLE			
GEAR	PITCH		SCALE
18T	0.45	0.9	1, 4
	0.3	0.6	13, 5
	0.25	0.75	
	0.5	1.5	
	1	3	1-6
	2		
	4	6	
20T	1.25	60	1, 4
	2.5		
21T	1.75	70	1, 3, 5
	3.5		


THREADING INDICATOR

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2327	THREAD BODY INDICATOR	1	
2	2328	THREAD DIAL BODY (INCH TYPE)	1	
3	2329	GEAR (M2x16T)	1	
4	2366	FLAT WASHER	1	
5	2365	CAP SCREW (6mmx12mm)	1	
6	2364	CAP SCREW (6mmx45mm)	1	
7	2336	THREAD CHART PLATE (IN TYPE)	1	
8	2328-1	THREAD DIAL BODY (METRIC TYPE)	1	
9	2330	GEAR (M1.25x18T)	1	
10	2331	GEAR (M1.25x20T)	1	
11	2332	GEAR (M1.25x21T)	1	
12	2366	FLAT WASHER	1	
13	2365	CAP SCREW (6mmx12mm)	1	
14	2337	THREAD CHART PLATE (METRIC TYPE)	1	




SADDLE & CROSS-SLIDE

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2401	SADDLE CASTING	1	
2	2402	CROSS-SLIDE	1	
3	2403	CLAMP REAR	1	
4	2404	GIB	1	
5	2405	CLAMP FRONT	2	
6	2406	CAP SCREW (7/16x2-1/2 IN)	1	
7	2407	WASHER	1	
8	2408	GIB	1	
9	2409	GIB SCREW	2	
10	2410	COLLAR	1	
11	2419	NUT	2	
12	2411	GEAR (M2x13T)	1	
13	2412	SCREW	1	
14	2413	NUT	1	
15	2414	KEEP ASSY	1	
16	2415	INDEX RING	1	
17	2417	HANDWHEEL	1	
18	2416	PLUG	1	
19	2418	HANDLE	1	
20	2439	WIPER	2	
21	2440	WIPER	2	
22	2465	DIAL	1	
23	2450	OILER (1/4 IN)	5	
24	2454	CAP SCREW (8mmx20mm)	3	
25	2453	SCREW AND NUT	1	
26	2451	CAP SCREW (8mmx16mm)	2	
27	2452	SCREW (3/16x1/2 IN)	8	
28	2466	CAP SCREW	2	
29	2467	PIN	2	
30	2462	CAP SCREW (8mmx20mm)	1	
31	2461	CAP SCREW (8mmx20mm)	1	
32	2460	KEY (5mmx12mm)	1	
33	2459	PIN (5mmx22mm)	1	
34	2457	THRUST (2902)	2	
35	2458	CAP SCREW (6mmx25mm)	2	
36	2468	NAIL (2mm)	2	
37	2456	STEEL BALL AND SPRING	1	
38	2455	SCREW (12mmx12mm)	1	
39	2464	WASHER	1	
40	2463	CAP SCREW (6mmx12mm)	2	




TOP-SLIDE

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2420	SWIVEL SLIDE	1	
2	2421	TOP-SLIDE (T-SLOT)	1	
3	2422	GIB	1	
4	2423	SCREW	2	
5	2424	NUT	1	
6	2425	LEAD SCREW	1	
7	2426	BRACKET	1	
8	2427	INDEXING RING	1	
9	2428	HANDWHEEL	1	
10	2429	GRIP (LONG)	1	
11	2430	GRIP (SHORT)	1	
12	2416	NUT	1	
13	2442	SPRING	1	
14	2431	PIN	1	
15	2432	BOLT	1	
16	2441	T-SLOT NUT	1	
17	2433	4-WAY TOOL POST	1	
18	2434	WASHER	1	
19	2435	HUB	1	
20	2436	LEVER	1	
21	2437	PVC KNOB	1	
22	2438	SCREW (3/8 IN)	8	
23	2443	DIAL	1	
24	2463	SET SCREW (6mmx12mm)	1	
25	2444	NUT	1	
26	2462	CAP SCREW (8mmx16mm)	2	
27	2445	STEEL BALL	1	
28	2469	SCREW	1	
29	2450	OIL CAP (1/4 IN)	3	
30	2464	KEY (4mmx10mm)	1	
31	2465	THRUST BEARING (51101)	2	
32	2466	CAP SCREW (6mmx25mm)	2	
33	2446	NAIL (2mm)	2	
34	2467	STEEL BALL & SPRING	1	
35	2455	SCREW (12mmx12mm)	1	
36	2468	SET SCREW	2	



TAILSTOCK


REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2501	TAILSTOCK CASTING	1	
2	2502	TAILSTOCK BASE	1	
3	2503	TAILSTOCK BARREL	1	
4	2504	NUT	1	
5	2505	FEED SCREW	1	
6	2506	BRACKET	1	
7	2507	DIAL	1	
8	2508	HANDWHEEL	1	
9	2509	NUT	1	
10	2510	HANDLE	1	
11	2511	NUT	1	
12	2512	SHAFT	1	
13	2513	LEVER	1	
14	2514	COLLAR	1	
15	2515	CAM SHAFT	1	
16	2516	CLAMP STUD	1	
17	2517	CLAMP	1	
18	2518	CLAMP HANDLE LEVER	1	
19	2519	STEEL BALL & SPRING	1	
20	2520	SET SCREW (8mmx30mm)	2	
21	2521	SET SCREW (8mmx30mm)	2	
22	2522	WASHER	1	
23	2523	NUT	1	
24	2524	CAP SCREW (8mmx20mm)	1	
25	2525	NUT	1	
26	2526	PVC KNOB	2	
27	2528	KEY (5mmx12mm)	1	
28	2529	THRUST BEARING(2902)	1	
29	2530	CAP SCREW (6mmx20mm)	3	
30	2531	SCREW (12mmx12mm)	1	
31	2527	DIAL	1	
32	2532	SCREW(3/16"x3/8")	2	




BED RACK LEAD SCREW AND SHAFTS

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2601	BED	1	
2	2602	GAP	1	
3	2603	RACK	1	
4	2604	RACK	1	
5	2605	LEAD SCREW (4 T.P.I.)(4 MM)	1	
6	2606	SHAFT	1	
7	2607	FOR/REV CONTROL,THIRD-ROD SHAFT	1	
8	2609	COLLAR	1	
9	2608	COLLAR	1	
10	2617	END BRACKET	1	
11	2611	BUSH	1	
12	2610	BOX	1	
13	2612	BUSHING	1	
14	2613	BRACKET	1	
15	2614	BUSH	1	
16	2615	BUSH	1	
17	2616	LEVER	1	
20	2634	SCREW (CAP 1/2"x2")	6	
21	2621	WASHER	6	
22	2622	NUT	6	
23	2623	SCREW (CAP 10mmx40mm)	2	
24	2624	SCREW (CAP 10mmx35mm)	2	
25	2632	SCREW (CAP 10mmx35mm)	4	
26	2633	SCREW TAPER PIN	2	
27	2627	NUT	2	
28	2636	SCREW (CAP 6mmx20mm)	6	
29	2635	PIN (5mmx28mm)	4	
30	2637	SCREW (SET 8mmx12mm)	1	
31	2638	STEEL BALL AND SPRING	2	
32	2639	SCREW (SET 8mmx10mm)	1	
33	2640	THRUST (#51104)	1	
34	2651	SCREW (8mmx60mm)	2	
35	2650	PIN (5mmx50mm)	2	
36	2658	PLUG	2	
37	2649	OIL CUP (1/4")	3	
38	2642	SCREW (SET 8mmx10mm)	1	
39	2641	SCREW (CAP 6mmx16mm)	2	
40	2628	SCREW (SET 6mmx16mm)	1	
41	2629	PIN (5mmx28mm)	1	
42	2643	SPRING	1	
43	2646	PIN (5mmx28mm)	1	
44	2644	SCREW (CAP 6mmx20mm)	2	
45	2645	SCREW (CAP 6mmx10mm)	1	
46	2648	SCREW (SET 8mmx8mm)	1	
47	2647	NUT	1	
48	2630	PVC KNOB	1	

CHUCK GUARD LIMIT SWITCH




CE COVER




CHUCK GUARD LIMIT SWITCH & CE COVER

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2901	COVER	1	
2	2912	CAP SCREW (8mmx20mm)	2	
3	2913	WASHER	2	
4	2914	ROD	1	
5	2911	SCREW (CAP 6mmx16mm)	1	
6	2906	SCREW (SET 8mmx20mm)	2	
7	2907	COLLAR	1	
8	2908	SCREW (SET 8mmx10mm)	1	
9	2909	COLLAR	1	
10	2910	FRAME	1	
11	2903	SCREW (CAP 8mmx55mm)	2	
12	2902	SWITCH AND COVER	1	
13	2904	SCREW (CAP 4mmx30mm)	2	
		<u>CE COVER</u>		
1	2617	END BRACKET	1	
2	2605	LEAD SCREW	1	
3	2624	ARM	1	
4	2622	PROTECTION HOOD	2	
5	2627	BUSH	1	
6	2623	ARM	1	
7	2621	COVER	1	
8	2206	SHAFT	1	
9	2205	COVER	1	
10	2606	SHAFT	1	
11	2609	COLLAR	1	
12	2608	COLLAR	1	
13	2651	SCREW (CAP 8mmx60mm)	2	
14	2650	PIN (5mmx50mm)	2	
15	2649	OIL CUP (1/4")	3	
16	2652	PLUG	2	
17	2640	THRUST (51104)	1	
18	2639	SCREW (SET 8mmx10mm)	1	
19	2638	STEEL BALL SPRING & SCREW	2	
20	2637	SCREW (SET 8mmx12mm)	1	
21	2661	SCREW (CAP 6mmx20mm)	2	
22	2659	SCREW (CAP 8mmx50mm)	2	
23	2653	PIN (5mmx50mm)	2	
24	2658	SCREW (CAP 8mmx16mm)	1	
25	2263	THRUST (51105)	1	
26	2255	SCREW (CAP 6mmx20mm)	3	
27	2660	SCREW (CAP 8mmx30mm)	2	







CABINET AND PANELS, PUMP SYSTEM

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2701	LEFT PEDESTAL HEAD-END	1	
2	2702	RIGHT PEDESTAL TAIL-END	1	
3	2704	CHIP PAN	1	
4	2705	SPLASH GUARD	1	
5	2709	COVER	1	
6	2708	COVER	1	
7	2707	CHUTE	1	
8	2703	FOOT BRAKE PEDAL	1	
9	2715	CONNECTOR SHAFT	1	
10	2716	COLLAR	1	
11	2714	LEVER	1	
12	2713	LEVER	1	
13	2712	COLLAR	1	
14	2711	BAR	1	
15	2745	SPRING	1	
16	2730	WASHER	1	
17	2719	BAR	2	
18	2718	CONNECT PLATE	1	
19	2710	NUT	2	
20	2732	SCREW (1/2"x2")	4	
21	2741	SCREW (6mmx12mm)	8	
22	2737	SCREW (CAP 6mmx12mm)	3	
23	2736	SCREW (CAP 8mmx20mm)	1	
24	2735	SCREW (CAP 6mmx16mm)	2	
25	2734	SCREW (CAP 8mmx20mm)	1	
26	2733	SCREW (CAP 8mmx20mm)	2	
27	2742	SCREW (SET 10mmx20mm)	2	
28	2743	SCREW (SET 10mmx40mm)	2	
29	2731	SCREW (CAP 8mmx10mm)	1	
30	2740	SCREW (8mmx10mm)	1	
31	2746	NUT	3	
32	2738	SCREW (CAP 8mmx25mm)	1	
33	2739	SCREW (8mmx30mm)	1	
34	2747	SCREW (6mmx16mm)	8	
35	2748	NUT	8	
36	2706	TANK	1	
37	2717	PUMP (1/8 HP)	1	
38	2720	HOSE	1	



SWING FRAME & GEARS, END COVER

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2801	SWING FRAM	1	
2	2802	BOLT	1	
3	2803	COLLAR	1	
4	2804	GEAR(M1.25x120T,127T)	1	
5	2805	SCREW	1	
6	2808	GEAR(1.25x60T)	1	
7	2806	COLLAR	1	
8	2807	GEAR(1.25x30T)	1	
9	2821	END COVER	1	
10	2822	STUD	1	
11	2824	STUD	1	
12	2823	NUT	2	
13	2833	BEARING(6202Z)	2	
14	2836	CIRCLIP(R 35)	1	
15	2835	NUT	2	
16	2837	WASHER	1	
17	2839	WASHER	2	
18	2840	SCREW(CAP 6mmx16mm)	2	
19	2838	NUT	1	
20	2831	WASHER	1	
21	2830	KEY (5mmx18mm)	1	
22	2841	KEY (5mmx18mm)	1	
23	2814	DATA PLATE	1	
24	2817	SCREW (3/16"x3/8")	6	
25	2809	CHANGE GEAR (M1.25x28T)	1	
26	2810	CHANGE GEAR (M1.25x35T)	1	
27	2811	CHANGE GEAR (M1.25x36T)	1	
28	2812	CHANGE GEAR (M1.25x49T)	1	
29	2815	CHANGE GEAR (M1.25x42T)	1	
30	2813	CHANGE GEAR (M1.25x38T)	1	
31	2816	CHANGE GEAR (M1.25x44T)	1	
32	2818	CHANGE GEAR (M1.25x52T)	1	
33	2825	CHANGE GEAR (M1.25x48T)	1	
34	2826	CHANGE GEAR (M1.25x56T)	1	
35	2819	CHANGE GEAR (M1.25x57T)	1	
36	2820	CHANGE GEAR (M1.25x65T)	1	



STEADY REST AND FOLLOW REST

REF.NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2901	CASTING	1	
2	2902	CASTING	1	
3	2903	SHAFT	5	
4	2904	SCREW	5	
5	2905	COLLAR	5	
6	2906	HANDLE	5	
7	2907	SHAFT	5	
8	2908	SCREW	1	
9	2909	HANDLE	1	
10	2910	SHAFT	1	
11	2911	SCREW	5	
12	2912	SCREW	5	
13	2913	SPRING PIN	5	
14	2914	SPRING PIN	1	
15	2915	CASTING	1	
16	2916	SCREW	2	

ELECTRIC EQUIPMENT

CONSTRUCTION

The electric equipment consists of spindle motor, control panel, magnetic contactor, magnetic switch, control cable and transformer.

1. The spindle motor is totally enclosed, 3 phase, 3 HP w/4 poles.
2. The control panel includes power on and off switches, coolant switch, and pilot lamp.
3. The magnetic control panel has spindle motor, reversible magnetic valve, and subsidiary magnetic contactor.
4. The forward and reverse motor control lever is controlled by a micro-switch.
5. A micro switch for foot brake pedal is fitted separately. When the pedal is pushed, the magnetic switch on the spindle motor will cut off automatically.

RUNNING STEPS

1. A power switch is fitted on the control panel. Turn this switch on , then the pilot lamp will come on.
2. Push or pull the motor control level on the apron will start the spindle.
3. When emergency stop is needed, step on the foot brake, then the power to the spindle will shut off automatically. Meanwhile, the brake is activated to stop the spindle.
4. Usually, when the machine need to stop, move the motor control lever to the middle position. Then the magnetic switch will be cut off, and the machine will stop running.
5. Upon operation is complete, be sure to put the power switch on the control panel to the off position.

DISMOUNTING THE GAP BED

First take off the four screws mounted on the surface, and remove the pin in the middle, then move the gap bed horizontally to get it off the machine. Be careful with its pin and edges! Hold the gap bed carefully, and do not bump it! Follow the opposite steps to put the gap bed back to the machine. Before re-mounting, gap bed and bed ways have to be cleaned.

NOTES

- 1. Be sure to operate the machine carefully and maintain it well. If so, the machine's longevity and precision can be assured.**
- 2. Everyday, when the operation is complete, be sure to clean out the chips on the machine, and oil the slideways to prevent rust. Turn off the power when done!**
- 3. Everyday, before operation, please make sure to check oil level on each gauge, and fill them if necessary. Especially the gear box, which is easily forgotten by the operator, please fill in oil every morning and in the afternoon before running the machine.**
- 4. For a new machine, after operation of three months, the oil in the headstock must be replaced or filtered if it will be re-used again. This is done so to protect the gears inside the headstock and reduce its noise level.**
- 5. If headstock is over heated, highly wobbled, oil leaked and oil short, please stop the machine and arrange a technician to solve the problem immediately.**
- 6. While clamping the work piece, please do not hit it with hammer or heavy material, otherwise the spindle might be damaged and loose its accuracy.**
- 7. After operation, hand tools, cutting tools, and clamping kits should be placed back to the original area. Please do not leave anything on the slideway or bed ways. This is to prevent collision of tools to the ways that ultimately will affect the accuracy of the machine.**
- 8. Besides the operator, please do not let anybody adjust or move the position of handles or controlling levers, or operate the machine.**
- 9. Please make a schedule of maintenance, and do it according to the schedule. This will elongate the life of the machine and prolong its accuracy.**













TROUBLE SHOOTING



TROUBLES	FACTORS	REMEDY
HEADSTOCK BEARINGS ARE OVER HEATED	<ol style="list-style-type: none"> 1. OIL LEVEL IN HEADSTOCK IS TOO LOW. 2. OIL VISCOSITY IS WRONG. 3. OIL PIPE IS OBSTRUCTED OR LEAKED. 4. MAIN SPINDLE IS WOBBLING OR OVER LOADED. 5. OIL FILTER IS OBSTRUCTED. 	<ol style="list-style-type: none"> 1. CHECK IF OIL LEVEL IN CORRECT POSITION AND FILL IT UP IF NECESSARY. 2. CHECK IF THE RECOMMENDED OIL IS USED. 3. CLEAN OIL PIPE OR REPLACE A NEW ONE IF NEED. 4. CHECK IF THE SPINDLE IS LOCKED UPON FREE RUNNING. 5. FILTER THE OIL OR REPLACE NEW OIL.
OIL LEAKAGE ON SPINDLE FLANGE OR GEAR BOX COVER	<ol style="list-style-type: none"> 1. BOLT IS LOOSE. 2. OIL PACKING IS WORN. 3. OIL VOLUME IS OVER. 4. OIL SEAL IS CRACKED. 5. THE SURFACE FINISH IS COARSE. 	<ol style="list-style-type: none"> 1. LOCK THE BOLT. 2. REPLACE THE PACKING. 3. LOWER THE OIL. 4. REPLACE OIL SEAL. 5. CORRECT THE FINISH.
CHATTER	<ol style="list-style-type: none"> 1. WORKPIECE IS NOT CLAMPED SECURELY. 2. WORKPIECE LEAVES TOO LONG AT LEFT SIDE OF THE CLAMPING POSITION. 3. IMPROPER CUTTING TOOL IS USED. 4. CUTTING TOOL IS TOO HIGH OR TOO LOW TO THE CENTER OF SPINDLE. 5. CHIP IS NOT REMOVED FREELY FROM THE TOOL. 6. WORKPIECE IS TOO LONG. 	<ol style="list-style-type: none"> 1. CLAMP IT SECURELY. 2. LESSEN THE LENGTH TO AVOID Wobble HAPPENED. 3. SELECT SUITABLE CUTTING TOOL ACCORDING TO MATERIAL OF WORKPIECE AND THE CUTTING SPEED. FOR SMALL DIAMETER OF WORKPIECE, A SMALL ANGLE OF CUTTING TOOL TO BE USED. IF OPPOSITE, USE THE BIG ANGLE OF CUTTING TOOL. 4. ADJUST THE CUTTING TOOL TO THE CENTER OF SPINDLE. 5. MOUNT A CHIP CUTTER OR ADJUST THE FRONT ANGLE OF CUTTING TOOL. 6. USE A CENTER TO SUPPORT LONGER WORKPIECE.
BENT FINISH ON LONG WORKPIECE CUTTING	<ol style="list-style-type: none"> 1. MATERIAL IS OVER HEATED. 2. DEEP CUT IS MADE. 3. HOT IS HAPPENED TO THE CENTER AND WORKPIECE. 	<ol style="list-style-type: none"> 1. USE COOLANT OIL FOR CUTTING. 2. REDUCE THE DEPTH FOR EACH CUTTING. 3. USE ROLLING CENTER FOR HIGH SPEED RUNNING.
PRECISION IS GETTING WORSE	<ol style="list-style-type: none"> 1. WORKPIECE IS NOT BALANCE CLAMPED. 2. ALWAYS HIT THE WORKPIECE BY HAMMER. 3. CENTER OF SPINDLE IS NOT ALIGNMENT WITH THE CENTER OF TAILSTOCK. 4. MACHINE IS OUT OF THE HORIZONTAL. 	<ol style="list-style-type: none"> 1. CLAMP WORKPIECE IN BALANCE 2. DO NOT HIT IT BY HAMMER. 3. ADJUST THE TAILSTOCK TO ALIGNMENT WITH THE CENTER OF SPINDLE. 4. CHECK PERIODICALLY HORIZONTAL OF MACHINE.
LEVER SWITCH IS HARD OPERATED	<p>THE OPERATOR IS NOT FAMILIAR WITH OPERATION OF THE MACHINE.</p>	<p>THE LEVER SWITCH IS FITTED WITH A SAFETY DEVICE. DURING OPERATION, THE LEVER MUST BE MOVED SLIGHTLY TO RIGHT THEN OPERATE UPWARD OR DOWNWARD FOR RUNNING THE SPINDLE CLOCKWISE AND ANTICLOCKWISE.</p>

TOLERANCE PERMISSIBLE DIAGRAM




I.ACCURACY TEST.(mm)

NO.	INSPECTION ITEM	DIAGRAM	TOLERANCE PERMISSIBLE
1	Straightness of bed slideway	a.Longitudinal direction (In vertical plane)	0.04
		b.Transverse direction (In vertical plane)	0.04
2	Parallelism of bed slideways.		0.02
3	Spindle nose runout		0.01
4	Spindle taper hole runout	a.Nearest spindle nose	0.01
		b.At a distance of 300mm	0.02
5	Parallelism of center line of main spindle to longitudinal motion of carriage	a.In vertical plane	0.025
		b.In horizontal plane	0.025
6	Movement of compound slide parallel with main spindle in vertical plane (Hand feed)		0.01/150

NO.	INSPECTION ITEM	DIAGRAM	TOLERANCE PERMISSIBLE
7	Main spindle for axial slip. measured at 2 points, displaced by 180°		0.015
8	True running of center point of main spindle.		0.015
9	Parallelism of tailstock spindle with bed ways.	a. In vertical plane (Front end rising)	 0.015/100
		b. In horizontal plane (Front end inclined towards the direction of tool pressure.)	 0.015/100
10	Parallelism of bed ways with center line of tailstock spindle hole.	a. In vertical plane (Free end of mandrel rising)	 0.02/300
		b. In horizontal plane (Free end of mandrel inclined towards tailstock end)	 0.02/300
11	Difference in center height between headstock and tailstock (Mandrel rising towards tailstock end)		0.025
12	Squareness of motion of cross slide with center line of main spindle		0.02/300
13	Parallelism of center line of lead screw end bearing to carriage slide ways	a. In vertical plane	 0.1
		b. In horizontal plane	 0.1
14	Diviations in alignment of center line of lead screw end bearing with center line of half nut.	a. In vertical plane	 0.15
		b. In horizontal plane	 0.15

NO.	INSPECTION	DIAGRAM	TOLERANCE PERMISSIBLE
15	Axial displacement of lead screw by turning		0.01
16	Pitch error of lead screw		0.03/300

2. PRACTICAL

NO.	TESTING ITEM	DIAGRAM	TOLERANCE PERMISSIBLE
1	Accuracy of outside turning		0.01
2	Accuracy of cylindrical turning		0.025
3	Accuracy of face turning		0.02

3. CHECK OF MOTOR SPECIFICATION

ITEM	HP	Ph	V	Hz	R.P.M.
Rating	2 3	1 3		50 60	1420 1700
Actual					