

AEROPRO

INSTRUCTION MANUAL



Air Belt Sander Model No.: AP7322



IMPORTANT:

Upon receipt of the product, read and follow all safety rules, operating instructions before first use it. And retain this manual for future reference.

Contain:

- Specifications
- General Safety Information
- Features & Operation
- Maintenance
- Troubleshooting
- Parts List



2016

※ Technical Data

Sanding Pad.....	(10-12) mm x 330mm
Free Speed RPM.....	16,000RPM
Avg. Air consumption.....	6.47cfm (183.3 l/min)
Operating pressure.....	90psi (6.3bar)
Air inlet size.....	1/4"
Air Hose.....	3/8"ID
Weight.....	0.8LBS (1.76kgs)

※ Important Safety Rules

1. Always wear safety goggles , face mask or respiratory equipment.
2. Always ensure machine is switched off before connecting to air supply.
3. Disconnect any machine from the air supply before changing chisels and before servicing any type of machine.
4. Always keep your air tool clean and lubricated. Daily lubrication is essential to avoid internal corrosion and possible failure.
5. Do not wear watches, rings bracelets or loose clothing when using air tools.
6. Using only light weight coil hoses from a tool to the wall or compressor coupling.
7. Do not overload the machine. Allow the tool to operate at its optimum speed for maximum efficiency.
8. Do not increase the air pressure above the manufacturers recommended level, as excessive overload can cause the machine casing to split. Also this creates excessive wear on moving parts and possible failure.
9. In the interests of safety and possible damage to the machine/operator, always ensure that the machine has

stopped before putting it down after use.

10. Always ensure that the work piece is firmly secured leaving both hands free to control the machine.

11. Always ensure that the accessories such as blades, discs, sockets, etc. are rated / designed for use with the machine. Also correctly and securely fastened before connecting the machine to the air supply.

✂ Operating Instruction

Description

The belt will rotate 120° and allow sanding in normally inaccessible working areas such as internal surfaces and narrow corners.

- Smooth& controlled in very tight areas
- Deburr edges of sheet metal or plate steel
- Remove casting marks
- Weld grinding

Air supply

1. Ensure air valve (or trigger) is in the “off” position before connecting to the air supply.
2. You will require an air pressure of 90psi, and an air flow according to specification.
3. **WARNING!** Ensure the air supply is clean and does not exceed 90psi while operating the tool. Too high an air pressure and unclean air will shorten the product life due to excessive wear, and may be dangerous causing damage or personal injury.
4. Drain the air tank daily. Water in the air line will damage the tool.
5. Clean air inlet filter weekly.
6. Line pressure should be increased to compensate for unusually long air hoses (over 8 metres). The hose diameter should be 3/8” I.D.
7. Keep hose away from heat, oil and sharp edges. Check hose for wear, and make certain that all connections are secure.

Lubrication

An automatic in-line filter-regulator-lubricator is recommended (Fig4) as it increases tool life and keeps the tool in sustained operation. The in-line lubricator should be regularly checked and filled with air tool oil.


Proper adjustment of the in-line lubricator is performed by placing a sheet of paper next to the exhaust ports and holding the throttle open approximately 30 seconds. The lubricator is properly set when a light stain of oil collects on the paper. Excessive amounts of oil should be avoided.

In the event that it becomes necessary to store the tool for an extended period of time (overnight, weekend, etc.), it should receive a generous amount of lubrication at that time. The tool should be run for approximately 30 seconds to ensure oil has been evenly distributed throughout the tool. The tool should be stored in a clean and dry environment.

- It is most important that the tool be properly lubricated by keeping the air line lubricator filled and correctly adjusted. Without proper lubrication the tool will not work properly and parts will wear prematurely.
- Use the proper lubricant in the air line lubricator. The lubricator should be of low air flow or changing air flow type, and should be kept filled to the correct level. Use only recommended lubricants, specially made for pneumatic applications. Substitutes may harm the rubber compounds in the tools O-rings and other rubber parts.

IMPORTANT!!!

If a filter/regulator/lubricator is not installed on the air system, air operated tools should be lubricated at least once a day or after 2 hours work with 2 to 6 drops of oil, depending on the work environment, directly through the male fitting in the tool housing.



Loading and operation

⚠ WARNING: Ensure you read, understand and apply safety instructions before use.

1. Connect the tool to the air hose.
 2. Press the trigger to operate the tool.
 3. The flow of air may be regulated by adjusting flow valve at the base of the handle.
 4. Ensure the air supply is clean and does not exceed 90psi while operating the tool. Too high an air pressure and unclean air will shorten the product life due to excessive wear, and may be dangerous causing damage or personal injury.
- DO NOT use any additional force upon the tool.
- DO NOT allow tool to free run for an extended period of time as this will shorten its life.

✂ Maintenance

- ⚠ WARNING:** Disconnect tool from air supply before changing accessories, servicing or performing maintenance. Replace or repair damaged parts. *Use genuine parts only. Non-authorised parts may be dangerous*
1. Lubricate the air tool daily with a few drops of air tool oil dripped into the air inlet
 2. DO NOT use worn, or damaged tool.
 3. Loss of power or erratic action may be due to the following:
 - a) Excessive drain on the air line. Moisture or restriction in the air pipe. Incorrect size or type of hose connectors. To remedy check the air supply.
 - b) Grit or gum deposits in the tool may also reduce performance. If your model has an air strainer (located in the area of the air inlet), remove the strainer and clean it.
 5. When not in use, disconnect from air supply, clean tool and store in a safe, dry, childproof location.

✂ Trouble Shooting


The following form lists the common operating system with problem and solutions. Please read the form carefully and follow it.

⚠ WARNING: If any of the following symptoms appears during your operating, stop using the tool immediately, or serious personal injury could result. Only a qualified persons or an authorized service center can perform repairs or replacement of tool. Disconnect tool from air supply before attempting repair or adjustment. When replacing O-rings or Cylinder, lubricate with air tool oil before assembly.

PROBLEMS	POSSIBLE CAUSES	REMEDIES
Tool runs at normal speed but loses under load	<ul style="list-style-type: none">■ Cam clutch worn or sticking due to lack of lubricant.	<ul style="list-style-type: none">■ Lubricating clutch housing.■ Check for excess clutch oil. Clutch cases need only be half full. Overfilling can cause drag on high speed clutch parts, ie. a typical oiled/lubricated wrench requires 1/2 ounce of oil. <p>GREASE LUBRICATED:NOTE: Heat usually indicates insufficient grease in chamber. Severe operating conditions may require more frequent lubrication.</p>
Tool runs slowly. Air flows slightly from exhaust	<ul style="list-style-type: none">■ Power regulator in closed position■ Air flow blocked by dirt.	<ul style="list-style-type: none">■ Check air inlet filter for blockage.■ Pour air tool lubricating oil into air inlet as per instructions.■ Operate tool in short bursts quickly reversing rotation back and forth where applicable.■ Repeat above as needed.

Tools will not run. Air flows freely from exhaust	<ul style="list-style-type: none"> One or more motor vanes stuck due to material build up. 	<ul style="list-style-type: none"> Pour air tool lubricating tool into air inlet. Operate tool in short bursts of forward and/or reverse rotation where applicable. Disconnect supply.
Tool will not shut off	<ul style="list-style-type: none"> 'O' rings throttle valve dislodged from seat inlet valve. 	<ul style="list-style-type: none"> Replace 'O' ring .
Note: Repairs should be carried out by a qualified person.		

Parts List



No.	Description	Qty.	NO	Description	Qty.	NO	Description	Qty.
1	Sealing Cover	1	17	O-ring	1	33	Belt Seat	1
2	O-ring	1	18	O-ring	1	34	Hex Bolt	1
3	Bearing	1	19	O-ring	1	35	Underprop Sleeve	1
4	End Plate	1	20	Switch Seat	1	36	Underprop Spring	1
5	Pin	1	21	Pin	1	37	Underprop	1
6	Cylinder	1	22	Trigger	1	38	Pin	2
7	Blade	5	23	Exhaust Cover	1	39	Spring	1
8	Rotor	1	24	O-ring	1	40	Wheel Seat	1
9	Straight Key	1	25	Muffle	1	41	Bolt	1
10	Sleeve	1	26	Nut	1	42	Bolt	1
11	Bearing	1	27	Dust-proof cover	1	43	Wheel Pin	1
12	Front plate	1	28	Belt Rotor	1	44	Bearing	2
13	Body	1	29	Hex nut	1	45	Wheel	1
14	Compressed Spring	1	30	Belt Rotor Cover	1	46	Hex	1
15	O-ring	1	31	Bolt	1			
16	Pin	1	32	Baffle	1			