



5.10 Electric Miter Saw

AJX255/DJX255/KJX255





No	Code	Name of Spare Parts	Remark
1	30021100091	Cross Recessed Small Pan Head Screw With Spring Washer M5×14	
2	30021600156	Flat Washer	
3	30019900082	Blade Guard	
4	30024500048	Torsion Spring(37.6×1.4×5.6)	
5	30021100196	Screw M6	
6	30021100032	Hex Flange Head Bolt M8×12	
7	30024000205	Center Cover	
8	30024000204	Center Plate	
9	30021100194	Set Screw M8×20 (Left Thread)	
10	30025200003	Flange	
11	30029900005	Bushing_Blade	
12	30025200003	Flange	
13	30020100034	Drive Spindle	
14	30021100045	Cross Recessed Pan Head Tapping Screw M5×18 (With Spring And Flat Washers)	
15	30024000206	Bearing Cover	
16	30021400346	Ball Bearing 6203DD	
17	30023700024	Bearing Retainer	
18	30020500075	Helical Gear	
19	30119900020	Guide Cover	
20	30021200028	Pan Head Tapping Screw ST4.2×18	
23	30021400040	Ball Bearing 688ZZ	
24	30023400018	Motor Bracket	
25	30010000076	Rubber Sleeve	
26	30021100031	Hex Bolt M8×75	
27	30021100024	Hex Socket Head Screw M6×30	
28	30019900160	Handle	
29	30021400231	Ball Bearing 6202DD-DC01	
30	30021600157	Flat Washer	
31	30100400058	Armature	220V
31	30500400336	Armature	220V
31	30200401016	Armature	220V
31	30400401013	Armature	220V
31	30400401592	Armature	220V
31	30500400186	Armature With Bearings	220V
31	30200401321	Armature With Bearings	220V
31	30400401304	Armature With Bearings	220V
31	30200401344	Armature	240V
31	30400401239	Armature	240V
31	30200401357	Armature With Bearings	240V
31	30400401388	Armature With Bearings	240V

No	Code	Name of Spare Parts	Remark
31	30400401438	Armature With Bearings	110V
31	30400401545	Armature	110V
32	30016300021	Insulation Washer	
33	30021400233	Ball Bearing 6000VV-DC02	
34	30021200026	Cross Recessed Pan Head Tapping Screw ST5×63	
35	30016000045	Baffle Plate	
36	30200600143	Stator	220V
36	30400600010	Stator	220V
36	30100600016	Stator	220V
36	30500600001	Stator	220V
36	30400600277	Stator	110V
36	30200600215	Stator	240V
36	30400600174	Stator	240V
37	30119900008	Snap Gauge(Blue)	
37	30219900006	Snap Gauge (Green)	
37	30319900005	Snap Gauge (Red)	
38	30024500051	Compression Spring (10.2×0.8×26.5)	
39	30024000211	Shaft Lock	
41	30115400111	Motor Housing (Blue)	
41	30515400112	Motor Housing(Red)	
41	30215400093	Motor Housing (Green)	
42	30040500004	Label2	
43	30030700007	Brush Holder Assembly	
44	30030600201	Carbon Brush	110V-240V
44	30530600018	Carbon Brush	Azimuth
45	30030800007	Brush Holder Cap	
46	30021100027	Pan Head Screw M6×60 (with Spring and Flat Washers)	
47	30030100007	Switch	220V, Lock-On
48	30024500052	Switch Spring (3.5×0.5×22)	
49	30030100006	Contact Switch	
50	30019900231	Lock-On Button(Black)	
51	30019900232	Lock-On Cam	
52	30019900233	Lock-On Lever	
53	30019900132	Switch Lever(Black)	
55	30030300075	Power Cord (European Standard Plug)	220V
55	30030300473	Power Cord (GB Standard)	220V
55	30030300154	Power Cord (British Standard Plug)	220V
55	30030300276	Power Cord (Australian Plug)	110V
55	30030300554	Brazilian Power Cord	220V
56	30010100034	Cord Guard (PVC)	

No	Code	Name of Spare Parts	Remark
58	30016300006	Strain Relief	
62	30021100030	Hex Bolt M8×30	
63	30021600048	Standard Spring Washer 8	
64	30021600058	Flat Washer 8	
65	30023000043	Guide Rule	
66	30021100026	Cross Recessed Countersunk Head Screw M6×22	
67	30019900226	Revolving Handle	
68	30023000042	Sub Fence	
69	30024000202	Sub Fence Plate	
70	30021300015	Lock Nut M6	
71	30040500006	Label3	
72	30020700020	Shaft	
73	30024500050	Torsion Spring (10.1×1.4×5.6)	
74	30024000212	Sub Shifter	
75	30021100081	Cross Recessed Small Pan Head Screw With Spring Washer M4×12	
76	30020700019	Connecting Rod	
77	30024000210	Shifter	
78	30010000058	Shifter Cover	
79	30021100025	Hex Socket Head Screw with Flat Point M6×10	
80	30025300018	Positioning Ring7×10×3	
81	30021600159	Washer	
82	30021100197	Positioning ScrewM6×14	
83	30024000213	Link Plate	
84	30024500049	Compression Spring (32×4×135.5)	
85	30024000207	Spring Holder	
86	30020700018	Holder Shaft	
87	30021500039	Stopper Pin	
88	30010300046	O Ring (4.5×1.3)	
89	30023000035	Rotating Base	
90	30140500001	Guide Rule	
91	30020700021	Rod	
92	30021600043	Flat Washer	
93	30021100195	Locking Screw M10×34	
94	30021100081	Cross Recessed Small Pan Head Screw With Spring Washer M4×12	
95	30019900225	Lever	
96	30019900236	L&R Metal Plate	
97	30121100030	Locking Screw M8×30	
98	30021300009	Hex Lock Nut M8	
99	30021300001	Hex Nut M8 (Non-Standard)	

No	Code	Name of Spare Parts	Remark
100	30021600058	Flat Washer 8	
101	30021100081	Cross Recessed Small Pan Head Screw With Spring Washer M4×12	
102	30024000209	Pointer	
103	30023000036	Turn Base	
104	30040500009	Label6	
105	30024100019	Base Complete	
106	30021600158	Slide Plate	
107	30019900204	Wing Screw M6×20	
108	30019900110	Locking Screw M6×30	
109	30040500015	Guide Rule	
110	30121100030	Locking Screw M8×30	
111	30021100091	Cross Recessed Small Pan Head Screw With Spring Washer M5×14	
112	30040500003	Label 1	
113	30024000208	Locking Spring	
861	30005090084	Vertical Vise (Incl. Vise Plate, Vise Screw, Vise Arm, Vise Knob, Wing Bolt, Vise Rod)	
862	30024000214	Holder Assembly	
863	30009800002	Dust Bag	
864	30025100008	Socket Wrench	
866	30019900264	Triangle Ruler	
867	30030400093	Terminal Block 2P	Areas where capacitors and inductors need to be assembled
868	30030400189	Capacitor&Inductance Assembly	Areas where capacitors and inductors need to be assembled
T1	30115600071	Handle Assembly-Blue	Including: 54、59
T1	30215600029	Handle Assembly (Green)	Including: 54、59
T1	30515600001	Handle Assembly-Red	Including: 54、59