



Parts List for CBS14B Band Saw ---Stand Parts

Index No.	Part No	Description	Q'TY
1	CBS14B-A01	Support parts	4
2	CBS14B-A02	Hex nut M8	32
3	CBS14B-A03	Washer ø8	36
4	CBS14B-A04	Carriage bolt M8×16	24
5	CBS14B-A05	Connected plate (1)	2
6	CBS14B-A06	Connected plate (2)	2
7	CBS14B-A07	Connected plate (3)	2
8	CBS14B-A08	Connected plate (4)	2
9	CBS14B-A09	Rubber washer	4
10	CBS14B-A10	Hex bolt M8×40	4

Parts Breakdown for CBS14B Band Saw ---Stand Parts



Parts Breakdown for CBS14B Band Saw



Parts List for CBS14B Band Saw

Index No.	Part No	Description	Size	Q'TY
1	CBS14B-001	Column Cover		1
2	CBS14B-002	Saw Body		1
3	CBS14B-003	Bush		2
4	CBS14B-004	Magnetic Switch		1
5	CBS14B-005	Hexagon Head Screw	M6×16	4
6	CBS14B-006	Motor		1
7	CBS14B-007	Dust Cover		1
8	CBS14B-008	Upper Door		1
9	CBS14B-009	Lower Door		1
10	CBS14B-010	Screw		2
11	CBS14B-011	Washer	4	15
12	CBS14B-012	Hexagon Nut	M4	8
13	CBS14B-013	Knob		2
14	CBS14B-014	Screw		2
15	CBS14B-015	Retainer		1
16	CBS14B-016	Semicircle Head Screw	M5×8	6
17	CBS14B-017	Washer	5	12
18	CBS14B-018	Spring Leaf		2
19	CBS14B-019	Hexagon Nut	M5	3
20	CBS14B-020	Hand Wheel		1
21	CBS14B-021	Screw		1
22	CBS14B-022	Washer	12	4
23	CBS14B-023	Guide Screw Pole		1
24	CBS14B-024	Spring		1
25	CBS14B-025	Square Nut		1
26	CBS14B-026	Steel Dowel		2
27	CBS14B-027	Guide Board Saddle		2
28	CBS14B-028	Washer	8	16
29	CBS14B-029	Hexagon Head Screw	M8×16	8
30	CBS14B-030	Upper Wheel Saddle		1
31	CBS14B-031	Small Triangular Frame		1
32	CBS14B-032	Upper Wheel Axle		1
33	CBS14B-033	Adjusting Handle	M8	1
34	CBS14B-034	Bearing	80203	4
35	CBS14B-035	Upper Saw Wheel		1
36	CBS14B-036	Blade		1
37	CBS14B-037	Axis Elastic Ring		4
38	CBS14B-038	Lower Saw Wheel		1
39	CBS14B-039	Semicircle Head Screw	M4×12	2

Index No.	Part No	Description	Size	Q'TY
40	CBS14B-040	Lower Wheel Axle		1
41	CBS14B-041	Hexagon Nut	M16	1
42	CBS14B-042	Hexagon Nut	M12	3
43	CBS14B-043	Motor Wheel		1
44	CBS14B-044	Washer	16	1
45	CBS14B-045	Adjusting Screw		3
46	CBS14B-046	Big Triangle Frame		1
47	CBS14B-047	Rubber Belt For Saw Wheel		2
48	CBS14B-048	Screw		1
49	CBS14B-049	Washer	10	1
50	CBS14B-050	Butterfly Nut	M8	2
51	CBS14B-051	Upper Blade Guard		1
52	CBS14B-052	Sliding Plate		1
53	CBS14B-053	Spacing Board		1
54	CBS14B-054	Tapping Screw		7
55	CBS14B-055	Connecting Board		1
56	CBS14B-056	Rack		1
57	CBS14B-057	Carriage Bolt	M8×25	1
58	CBS14B-058	Locking Plate		1
59	CBS14B-059	Carriage Bolt	M8×20	5
60	CBS14B-060	Locking Plate		1
61	CBS14B-061	Screw	M6×6	6
62	CBS14B-062	Cap Screw		6
63	CBS14B-063	Mount Shaft		2
64	CBS14B-064	Bearing	80026	6
65	CBS14B-065	Washer	6	24
66	CBS14B-066	Adjusting Shaft		4
67	CBS14B-067	Upper Guide Shaft		1
68	CBS14B-068	Connecting Bracket		1
69	CBS14B-069	Upper Guide Base		1
70	CBS14B-070	Lower Guide Shaft		1
77	CBS14B-077	Eccentric Shaft		1
78	CBS14B-078	Eccentric Bush		1
79	CBS14B-079	Washer	22	1
80	CBS14B-080	Hexagon Nut	M22	
81	CBS14B-081	Gear		1
82	CBS14B-082	Guide Plate		1
83	CBS14B-083	Worktable		1
84	CBS14B-084	Cap Screw	M6×12	8
85	CBS14B-085	Table Insert		1

Index No.	Part No	Description	Size	Q'TY
86	CBS14B-086	Screw		1
87	CBS14B-087	Front Fence Rail		1
88	CBS14B-088	Rotating Angle Rule		1
89	CBS14B-089	Stand Of Worktable		1
90	CBS14B-090	Side Insert		2
91	CBS14B-091	Pointer		1
92	CBS14B-092	Big Handle		1
93	CBS14B-093	Miter Gauge		1
94	CBS14B-094	Tapping Screw		4
95	CBS14B-095	Rolling Fixed Frame		1
96	CBS14B-096	Rear Fence Rail		1
97	CBS14B-097	Hexagon Nut	M8	6
98	CBS14B-098	Drawing Belt		1
99	CBS14B-099	Circles For Shaft		1
100	CBS14B-100	Bearing	80101	2
101	CBS14B-101	Press Wheel		1
102	CBS14B-102	Axle Of Press Wheel		1
103	CBS14B-103	Press Wheel Pole		1
104	CBS14B-104	Screw		1
105	CBS14B-105	Handle Of Press Wheel		1
106	CBS14B-106	Cap Screw	M6×65	4
107	CBS14B-107	Bush		4
108	CBS14B-108	Side Insert		2
109	CBS14B-109	Bearing Bar		1
110	CBS14B-110	Bearing	80027	1
111	CBS14B-111	Sliding Base		1
112	CBS14B-112	Shaft		1
113	CBS14B-113	Locking Handle		1
114	CBS14B-114	Locking Block		1
115	CBS14B-115	Plate		1
116	CBS14B-116	Spring Piece		1
117	CBS14B-117	Convex Window		1
118	CBS14B-118	Upper Guide Board		1
119	CBS14B-119	Semicircle Head Screw	M4×5	2
120	CBS14B-120	Semicircle Head Screw	M4×8	1
121	CBS14B-121	Carriage Bolt	M8×50	1
122	CBS14B-122	Plastic Square Washer		1
123	CBS14B-123	Fix Bush		1
124	CBS14B-124	Screw	M6×12	1
125	CBS14B-125	Semicircle Head Screw	M6×6	1

Index No.	Part No	Description	Size	Q'TY
126	CBS14B-126	Screw		1
127	CBS14B-127	Hexagon Nut	M6	1
128	CBS14B-128	Semicircle Head Screw	M5×14	1
129	CBS14B-129	Screw		1
130	CBS14B-130	Lid Shape Nut		2
131	CBS14B-131	Semicircle Head Screw	M4×30	4
132	CBS14B-132	Safety Switch		2
133	CBS14B-133	Semicircle Head Screw	M6×8	2
134	CBS14B-134	Hexagon Head Screw	M8×25	1
135	CBS14B-135	Rubber Washer		1
136	CBS14B-136	Pin		1
137	CBS14B-137	Pointer		1
138	CBS14B-138	Ring		2

