


CWL1018D / CWL1218D DIAGRAM



PARTS LIST

NO.	DESCRIPTION	QTY
1	Hand Wheel	1
2	Hex Socket Screw M6×12	4
3	Collar Spindle	1
4	Ball Bearing 80105	2
5	Hex SocketT Screw M8×25	4
6	Washer M8	4
7	Rear Belt Door	1
8	Moving Knob	1
9	Stationary Knob	1
10	Bolt	1
11	Semi-circle Head Screw	1
12	Headstock	1
13	Retaining Ring	2
14	Headstock Spindle	1
15	Face Plate	1
16	Headstock Spur Center	1
17	Lock Handle For Tool Rest Base	1
18	Retaining Ring 10	3
19	Tool Rest Bushing	1
20	Tool Rest	1
21	Tool Rest Base	1
22	Tool Rest Cam Follower	1
23	lock handle	2
27	live center	1
30	Tailstock Quill	1
31	Tail Axis	1
32	Tailstock	1
33	Eccentric Axis	1
34	Quill Adjusting Wheel	1
35	Quill Crank Handle	1
36	Bolt	1
37	Cam Follower Tailstock	1
38	Bed	1
39	Retaining Plate	1
40	Hex Socket Screw M10×12	2
41	Lock Plate	2
42	Nut M10	1
43	lock handle	1
47	Hex Socket Screw M8×12	1
48	Motor Plate	1

49	Big Washer	3
50	Washer 6	3
51	Motor Pulley	1
52	Drive Pulley	1
53	Drive Belt--3PJ685 (for MC1218VD)	1
54	Bolt	1
55	Washer	1
56	Door Latch	1
57	Washer 4	1
58	Hinge	2
59	Semi-circle Head Screw M4×8	2
60	Switch-box Plate	2
61	Pin Hinge	1
62	Power Cord	1
63	Overload Protector	2
64	Line Board	1
65	Semi-circle Head Screw M4×6	4
66	Switch-box	1
67	Knob	1
68	Switch	1
69	Hex Socket Taper Screw M6×12	1
70	Motor	1
71	Rubber Washer	4
72	Nut M8	1
73	Retaining Ring	1
74	Washer	4
76	Flat Head Screw	3
77	Extension Bed	2
78	Plate	2
79	Screw	1
80	Cover	1
81	Variable Plate	1
82	Screw	2
83	Transformer	1

