

SPARE PARTS LIST FOR WOOD CHIPPER GBK-150

Dia.no.	Part Name	Qty
1	Engine	1
2	Left Wheel	1
3	Right Wheel	1
4	discharge hopper downer	1
5	discharge hopper upper	1
6	Deflector	1
7	Knob M8	1
8	Flat Washer	26
9	Hex Bolt	1
10	Hex Bolts	1
11	M10 Knob	1
12	Adjustable buckle	2
13	Lock nuts	8
14	Spring Washer	8
15	Flat Washer	16
16	Hex bolts	6
17	Lock nuts	27
18	Spring Washer	44
19	Flat Washer	68
20	Hex bolts	13
21	Hand grip	2
22	Engine base plate	1
23	Loct nuts	23
24	Spring Washer	23
25	Lower space sleeve	4
26	Bearing Seat including bearing	2
27	Bearing seat Cover	1
28	Chipping Room	1
29	Hex bolts	4
30	Connect Tube	1
31	Towbar	1
32	Wire Hardness	1
33	Hex Bolt	2
34	Support Leg	1
35	Rubber pad	2
36	Hex bolts	4
37	Bolts	2
38	Emergench Stop	1
39	Spring	1
40	Hex bolts	1
41	Feed Hopper Assembly	1
42	Safety Bar	1
43	Splash Plate	1
44	Splash plate presser	1
45	Small Pulley	1
46	Belt Cover	1
47	Belt	2
48	Big Pulley	1
49	trailer	1
50	Flat Key	1
51	Flat Washer	2
52	Hex bolts	1
53	Flat Key	1
54	Small Pulley Shaft Sleeve	1
55	shaft sleeve	2
56	Belt Cover Side Plate	1
57	Upper Sleeve	2
58	Bearing Seat Fixed Plate	1
59	Blade	2
60	Hexagon socket round head screw	10
61	Blade drum	1
62	Blade adjustment block	1
63	Flat Washer	2
64	Wheel Axle Frame	1
65	Hex Bolt	6
66	Hex Bolt	11
67	Hex Bolt	6
68	Shaft Retaining Ring	1
69	Hexagon socket round head screw	4

