



**BOMBA DE AGUA
MODELO: AB9 113 16**



NUM	Description	Descripcion	NUM	Description	Descripcion
1	Discharge plug	Conector de salida	19	Bearing	Rodamiento
2	"O" ring	Junta torica	20	Split ring	Seguro
3	Charge plug	Conector de entrada	21	Screw	Tornillo
4	"O" ring	Junta torica	22	Terminal cover	Tapa de caja de conexión
5	Gauge plug	Tapon	23	Capacitor	Capacitor
6	Switch plug	Tapon	24	Terminal box	Caja de coneccion
7	Pump casing	Carcasa	25	Screw	Tornillo
8	"O" ring	Junta torica	26	Screw	Tornillo
9	Venturi pipe	Tubo venturi	27	Terminal board	Placa de terminales
10	"O" ring	Junta torica	28	Casing with wound stator	Carcasa y estator
11	Diffuser	Difusor	29	Screw	Tornillo
12	Impeller	Impulsor	30	Cable presser	Prensacable
13	"O" ring	Junta torica	31	Fairlead	Pasa cables
14	Mechanical seal	Sello mecanico	32	Stand	Soporte
15	Pump support	Soporte	33	Driving cap	Tapa
16	Bolt	Tornillo	34	Tie-rod	Tornillos
17	Key	Chaveta	35	Fan	Turbina
18	Rotor shaft	Eje de rotor	36	Fan cover	Cubierta de turbina

BOMBA DE AGUA
MODELO: AB9 113 16

